

KURUTTO 3 ⓘ

B

CARMATE



AILEBEBE

2070988A

KURUTTO 3 ⓘ



Installing



Placing





Adjusting



Cleaning

B

20150224版



CHANGE



4



10



18






24

B - 2



B - 3






1



2





3




B - 4

B - 5




B - 6




B - 7





CHECK



B-7




B-7




B-7

B-8



A-10




NEXT PAGE ▶▶▶


B-9





birth ~ 13kg





9kg ~ 18kg






1



2






3









4



5




6










CHECK



B-18



B-20



B-14

???

⊘ →

▶▶▶

A - 11 12

⊘ → OK




NEXT PAGE ▶▶▶

B-15







birth ~ 13kg

7




9kg ~ 18kg

7




B - 16


B - 17



1




2






birth~7kg




7kg~8kg




a



8kg~



b



c






A

10

B - 20



a





B - 21




b




c




Memo




1 B-21



2 B-22
A-14



3 A-15




B-24

B-25




4






A - 13 14 15 16

B - 26

5



6







B - 27




7

8



CHECK



OK

B - 28

B - 29



A - 14

B - 20

Where to contact

GLOBAL

CAR MATE MFG. CO., LTD.
5-33-11, Nagasaki, Toshima-ku, Tokyo 171-0051
Japan
E-mail: int@carmate.co.jp
Tel: +81-3-5926-1226

中国大陆

快美特汽车精品（深圳）有限公司
深圳市龙华新区龙华街道东环二路 78 号
Tel: 0755-2752 3500 Fax: 0755-2812 9944
E-mail: carmate_support@carmate.com.cn
<http://www.carmate.com.cn>

日本国内

株式会社 カーメイト
本社/〒171-0051 東京都豊島区長崎5-33-11
パソコンから: <http://www.carmate.co.jp/support/>
Tel: 03-5926-1212
FAX: 03-5926-1218
電話受付時間
＜平日＞10:00～18:30
＜土・日・祝＞10:00～12:00/13:00～18:30
※ 年始及び盆期間の一部等は休業日とさせていただきますのでご了承ください。