

AILEBEBE SWING MOON

Errata for the operating instructions

Some of the illustrations and names of parts in the operating instructions are modified because of specification changes. Please check these corrections.

<Error>

Page 34 in the operating instructions

5. Usage in Junior Style

Covering the body

7

Fix the 2 hooks (left and right) at the end of each black elastic strings inside the cover. Place the body cover on the seat and fix it with 4 hooks.

* If it is difficult to fix the hooks at the ends of the black elastic strings, first release the 2 hooks of the body cover to make it easy. Then try again to fix the released hooks.

Rear of the body cover

Turned-up cover

Black elastic string

Hook hole

Hook at the end of the black elastic string

Surface of the body cover for the seat

Hooks

* If it is difficult to fix the hooks at the ends of the black elastic strings, first release the hooks.

⚠ Caution

If the child seat is set to the 2nd or 3rd step of reclining, the inner hook of the cover can be put in an improper hole, in which case it may be possible that the child seat cannot be reclined.

<Correction>

Page 34 in the operating instructions

5. Usage in Junior Style

Covering the body

7

Place the cover on the seat, then fix it onto the waist parts and front parts, in that order.

Seat

Waist parts

Front parts

<Error>

Page 41 in the operating instructions

6. Maintenance

Removing the body cover

1

Release the 8 outer hooks and 2 inner hooks.

Rear of the body cover

Turned-up cover

Black elastic string

Hook hole

Hook at the end of the black elastic string

Outer hooks

Outer hooks

Inner hooks

Outer hooks

<Correction>

Page 41 in the operating instructions

6. Maintenance

Removing the body cover

1

Release the hooks, the waist parts, and front parts then remove the body cover.

Hooks

Waist parts

Front parts

<Error>

Page 42 in the operating instructions


6. Maintenance

Reattaching the cover

- 1 Pass the shoulder harnesses and tongues through the body cover. (child style only)




- 2 Cover the seat with the body cover and fix the 2 hooks (left and right) at the ends of the black elastic strings inside the cover.




Caution

If the child seat is set to the 2nd or 3rd step of reclining, the inner hook of the cover can be put in an improper hole, in which case it may be possible that the child seat cannot be reclined.

- 3 Pass the buckle through the body cover and fix the 8 outer hooks (only for the child style).



- 4 Cover the headrest with the headrest cover and fix the 2 pieces of fastener tape and 2 hooks.




<Correction>

Page 42 in the operating instructions

6. Maintenance

Reattaching the cover


- 1 Pass the shoulder harnesses, tongues, and buckle through the body cover. (child style only)



- 2 Cover the seat with the body cover.



- 3 Fix the body cover with the hooks, waist parts, and front parts, in that order. (child style only)



- 4 Cover the headrest with the headrest cover and fix the fastener tapes and hooks.

